








U1		S1CSG1K08	
P1.4	1	P1.4/ADC1/MISO/ECSDA/X320/CCP1_3/TK4/COM4	COM1/TK1/CCP0/ADC1/P1.1
P1.5	2	P1.5/ADC5/SCLK/TKCS/CLKX321/CCP2_3/TK5/COM5	COM0/TK0/CCP1/ADC0/P1.0
P1.6	3	P1.6/ADC6/RxD_3/MCLK0_2/TAL0/TK6/COM6	SEG7/TK15/CMP-/CCP2_2/INT3/P1.7
P1.7	4	P1.7/ADC7/TxD_3/XTAL1/TK7/COM7	SEG7/TK14/CMP-/CCP1_2/RxD_2/INT2/ADC14/P3.6
P1.3	5	TK3/AP	16 P3.5
TK3/AP	6	TK3/AP	15 P3.4
P5.4	7	TK3/CAP	14 P3.3
VCC	8	P5.4/ADC3/MOSI/TCLK0/EC1/CCP0_3/TK3/COM3	SEG4/TK12/MOSI_4/CMP0/ECL_2/TKCLRO/ADC12/P3.4
VREF	9	AVCC/VCC	SEG3/TK11/ECSDA_4/MISO_4/INT1/ADC11/P3.3
GND	10	VREF-/AGND/GND	SEG2/TK10/ECSCL_4/SCLK_4/INT0/ADC10/P3.2
			SEG1/TK9/TxD/ADC9/P3.1
			SEG0/TK8/INT4/RxD/ADC8/P3.0



严禁 2 个 USB 插口同时使用，以防短路



2.5V基准